



SL0023 SMARTlift Display - Cold Weather Operation

Date: 18 Jan 08	Author: Richard Brown	Version 1	SMARTlift
-----------------	-----------------------	-----------	-----------

The SMARTlift display screen contrast can be affected by low temperatures i.e. -10°C.

If you experience this, it is possible to adjust (increase) the contrast of the screen making it more visible.

Hold in the top button and turn the **Display Dial** clockwise until the screen image becomes clear again.

If the images become too dark in warmer conditions, reduce the contrast by holding in the top button and turning the **Display Dial** anti-clockwise until image becomes clear again.

